



SPARK
electric car sharing

Charging Instructions

Charging in 3 Easy Steps

1. Open the Charging Port Cover

A light push should open it. If locked, use the remote control's unlock button. Some models (e.g., Renault Zoe, Hyundai IONIQ) require pressing a button near the steering wheel or pulling a lever (Dacia Spring).

2. Connect the Cable

Remove the cable from the station and insert it into the car's port.

3. Start Charging

- a. **Standard AC or Fast DC (ChaDeMo):** Call our contact center at +359 2 419 34 76 and provide the station number.
- b. **Fast DC (CCS):** Plug in the connector, and charging will start automatically.

Note: The new Renault Zoe 40 only charges at standard AC stations, up to 22 kW per hour.

Charging Port Location

- **Side, Rear:** BMW i3, Hyundai IONIQ, Opel Corsa-e, Peugeot e-208, Skoda CITIGO, VW e-UP!
- **Front under the emblem:** Dacia Spring, Hyundai KONA, Nissan Leaf, Nissan ENV200, Renault Zoe

Stopping Charging

- **Fast-Charging Station (DC):** Press the STOP button on the station.
- **Standard Type 2 (AC) Station:** Call +359 2 419 34 76. If the cable is locked, use the car's unlock button.

Charging at Home

- A special "Schuko" type charging cable is needed. Request one by calling +359 2 419 34 76.

Sofia: Pickup from "Killer" at 22 Abagar Street, Sofia Logistic Park, behind Tsarigradsko Shose Blvd.

Plovdiv: By prior arrangement.

How to get 150 eGO points for charging?

- Charge a SPARK car with this symbol  at an Eldrive station and get 150 eGO points. The charging session should be started before ending your SPARK session.

Note: Station operating hours may vary. Please check the Eldrive website for details.